


STN 06

A-B PLC


DL3500 DH+ Network Bridging Protocol



High-12

A-B PLC

DH+ "A" Network-10 A-B PLC High-16 Modem Radio,Optical or **Telephone Connection** DH+ "C" Modem Network-01 High-02 Note: PLC's on DH+ A can communicate with PLC's on DH+ "B" and DH+ "C" but DH+ "B" cannot communicate with DH+ "C"



STN 02

DH+ "A" can communicate with DH+ "B" and "C". DH+ "B" can communicate with DH+ "C". DH+ "C" can communicate with DH+ "B".