


Wiring Diagrams: DL4000


1. Configuration Cable DL4000-CHA RS-232
2. Online Cable DL4000-CHA – No Handshaking
3. Online Cable DL4000-CHB – No Handshaking




4. Online Cable DL4000-CHA RS-232C – With Handshaking



5. Online Cable DL4000-CHB RS-232 – With RTS/CTS Handshaking



6. Online Cable DL4000-CHA RS422/RS485
7. Online Cable DL4000-CHB RS422/RS485



Note: 4 Pin Connectors are numbered from Left to Right
For RS485 Jumper Pins 1-2 and 3-4 for - and + wires

8. Online Cable DL4000-CHC RS232

